

Installation Instructions for B-021 & B-022S



Parts Included:

- Glass Counsel Top
- Wall Mounting Brackets
- Mounting Ring
- Towel Bar
- Waste Trap Cover

STEPS TO INSTALL

1. Mount Wall Brackets Approx. 22 9/16" On Center
2. Wall Brackets Screws about 4 1/2" center top hole to center bottom.
3. Mount top to wall, usually approx. 29" from the floor OR TO DESIRED HEIGHT, Make Plumb & Level.
4. Carefully mount glass counter top making sure glass over hang is equal on both sides. Make plumb & Level.
5. Attach towel bar.
6. Mount Bowl to top: (Put Drain through bowl, then mounting ring, through top tightens by hand plus 1/2 turn. Do NOT over tighten.
7. Mount faucet and trap assembly (Not provided).

Please Note: console should be attached to wall using appropriate fasteners. If sheet rock over stud construction console should be affixed to the studs.