

Installation Instructions for P-006



Parts Included:

- Counter Mount Bracket
- Counter Top/Bowl Glass
- Front Towel Bar
- Flow Through Drain
- Trap Cover

STEPS TO INSTALL

1. Mount corner brackets to wall (Approx 33" from floor or to your desired height). Make level & plumb.
2. Attach towel bar provided if you choose (optional)
3. Carefully place top/Bowl onto corner bracket.
4. Mount drain and faucet. Both hand tight plus ½ turn.
5. Attach drain cover with a nut (Not provided) after drain but prior to P-Trap attachment.

Please Note: Glass top is meant for 90 degree corner. Installer is responsible for any variance of actual walls.